

# WARNING NOTE

**Please do not forget to enter the RMS limiter data from the sheet into the IPD to avoid speaker damage!**

**RMS Limiters are hidden in USER MODE.  
Please follow the instructions to reveal the  
RMS Limiter in IPD via IntelliDrive.**

1. Download and install the latest PC version of the **IntelliDrive Controller Software**:  
<http://labgruppen.com/support/download-all>
2. Download and unzip the latest version of the **HK AUDIO Sheet Library Zip File**:  
[www.hkaudio.com](http://www.hkaudio.com)
3. Connect your computer to the IPD via Router or WiFi Router, then start IntelliDrive
4. Select the desired IPD by pressing the MIXER Button
5. Open the HK AUDIO DEFAULT presetfile: MENU > FILE > OPEN 02\_HK\_DEFAULT\_RMS.icpreset
6. Enter the password "**HKrms**" to open developer mode with RMS Limiters (Levels) displayed:  
MENU > Hardware > Enter Password
7. Open the desired preset sheet and enter the data incl. **OUTPUT RMS LIMITER VALUES**
8. Protect the controller against unauthorized users. The default hardware password is "**Password**".

Version	File Name	Comments
<b>CADIS</b>		
V01	HKAUDIO_CADIS_FilterSheet_LAB_IPD_20150430.pdf	Do not forget to unlock and enter RMS LIMITER VALUES!
<b>CONTOUR ARRAY</b>		
V01	HKAUDIO_CONTOUR_ARRAY_FilterSheet_LAB_IPD_20150430.pdf	Do not forget to unlock and enter RMS LIMITER VALUES!
<b>CONTOUR</b>		
V01	HKAUDIO_CONTOUR_FilterSheet_LAB_IPD_20150430.pdf	Do not forget to unlock and enter RMS LIMITER VALUES!
<b>ELEMENTS</b>		
V01	HKAUDIO_ELEMENTS_FilterSheet_LAB_IPD_20150430.pdf	Do not forget to unlock and enter RMS LIMITER VALUES!
<b>IL</b>		
V01	HKAUDIO_IL_FilterSheet_LAB_IPD_20150430.pdf	Do not forget to unlock and enter RMS LIMITER VALUES!
<b>LINEAR 5</b>		
V02	HKAUDIO_LINEAR5_FilterSheet_LAB_IPD_20151016.pdf	Do not forget to unlock and enter RMS LIMITER VALUES!
<b>VORTIS</b>		
V01	HKAUDIO_VORTIS_FilterSheet_LAB_IPD_20150430.pdf	Do not forget to unlock and enter RMS LIMITER VALUES!
<b>CONTOUR X</b>		
V01	HKAUDIO_CONTOURX_FilterSheet_LAB_IPD_20180607.pdf	Do not forget to unlock and enter RMS LIMITER VALUES!